


SINGLE ROW ZZ BALL BEARING



SR.NO.	BEARING NO.	d	D	B
1	623 ZZ	3	10	4
2	603 ZZ	3	9	5
3	684 ZZ	4	9	4
4	624 ZZ	4	13	5
5	625 ZZ	5	16	5
6	685 ZZ	5	11	5
7	686 ZZ	6	13	5
8	696 ZZ	6	15	5
9	626 ZZ	6	19	6
10	688 ZZ	8	16	5
11	698 ZZ	8	19	6
12	608 ZZ	8	22	7
13	628 ZZ	8	24	8
14	61900 ZZ	10	22	6
15	6000 ZZ	10	26	8
16	6200 ZZ	10	30	9